

Mounting the Sauer 404 Adapter

Observe the «fingers» of the lock in the picture below. They are stiff but free to flex. You can insert the part into the stock QD sling attachment point when the fingers are in this position. It requires quite a bit of force and a little “wiggle” for it to snap into place.



In the picture below the key is opened, and the parts are ready to be inserted into the rifle stock. A rail with QD is used for illustrative purposes.

Once inserted in the stock, rotate so it sits vertical, and tighten the key gradually, making sure to take out any slack. The Sauer 404 front QD has grooves inside that you need to **snap the fingers into contact with**. It should be firmly locked with the allen key. The short end of the allen key turned by hand is enough force. Check this occasionally.



Inserted into a Riflestock it will look like this when entered properly. (Valhalla edition)



This adapter is not fully inserted into the stock. It may move or come loose.

Below is a picture of WRONG mounting of the adapter. This will fall out.

Video of mounting:

<https://youtu.be/eAZ1NBouzYo>

Any questions, contact kskorpen@antikythera.no

😊 Happy hunting!